

# noribachi UFO HIGH BAY Installation Instructions

## **WARNING!**

### **IMPORTANT SAFEGUARDS:**

Read and Follow all safety instructions before installation! Save these instructions and deliver to owner after installation.

### **IMPORTANT:**

Read all instructions carefully before attempting installation. If you do not understand these instructions, please consult your local distributor. Thoroughly inspect your fixture for any freight damage; freight damage should be reported to the delivery carrier.

### **WIRING CONNECTION**

1. Connect the brown AC fixture wire to the brown supply wire (line).
2. Connect the blue AC fixture wire to the blue supply wire (neutral).
3. Connect the green AC fixture wire to the green supply wire (ground).



### **010V Dimming CONNECTION (If Applicable)**

4. Connect the blue wire to the (+) 010V dimming connection.
5. Connect the white wire to the (-) negative dimming connection.

### **MOUNTING**

1. Hang the luminaire by the eyehook provided on the top of the fixture at your desired indoor location.
2. Ensure that the desired location is structurally sound for this fixture.

### **TROUBLESHOOTING TIPS**

1. Verify proper line voltage is present and wired to the correct input voltage lead.
2. Verify fixture wiring.
3. Verify fixture is grounded.